



Features

- Dual axis measurement, range from ± 5 to $\pm 45^\circ$
- High resolution and accuracy
- Designed for subsea & marine applications
- Rated for use at 500m depth below sea
- Fitted with a SubConn Micro subsea connector
- Low temperature drift
- Single-drop RS232, RS485 or multi-drop RS485 interface with ModBus protocol
- Compact & stainless steel: 70 x 93 x 27mm
- CE certified and RoHS compliant



Description

The SUBSEA-2 series inclinometers are specifically designed for installation on underwater structures or equipment & are rated for use up to 500m below sea level. They are a range of high performance dual axis tilt sensors for measurement of angle in both pitch and roll axes. These devices are available with standard measurement range options of $\pm 5^\circ$, $\pm 15^\circ$, $\pm 30^\circ$ and $\pm 45^\circ$. The housing is a rugged and compact stainless steel assembly. They utilise a very high performance

MEMS sensor which exhibits low long term drift and excellent temperature stability when compared with competitive devices. It has an RS232 and RS485 interface option with our standard communication protocol as well as a version with RS485 multi drop ModBus communication protocol. They are CE and RoHS certified, and are manufactured, calibrated and tested in our UK factory to guarantee performance to the stated specification.

General Specifications

Parameter	Value	Unit	Notes
Supply Voltage	9-30	V dc	Supply is filtered, suppressed and regulated internally, however we recommend the use of a low noise supply to prevent noise coupling to the sensor.
Operating Current	30mA (@ 9V) 20mA (@ 12V) 10.5mA (@ 24V)	mA	Supply current depends on supply voltage.
Operating Temperature	-40 to 85	°C	Maximum operating temperature range. Units can be calibrated between -20 and 70°C on request.
RS232/485 Output Rate	38400	bps	Bit rate is adjustable between 115.2k, 57.6k, 38.4k, 19.2k, 9.6k, 4.8k and 2.4k via the digital interface. See page 6 for more details.
RS232 Data Format	38.4, 8,1,N		1 start bit, 8 data bits, 1 stop bit, no parity. See page 6 for more details.
RS485 & ModBus Format	38.4, 8,1,N		1 start bit, 8 data bits, 1 stop bit, no parity. See page 6 for more details.
Frequency Response	1	Hz	This is the frequency at which the output is 3dB less than the input value, adjustable between 16Hz & 0.125Hz via the RS232/RS485/ModBus control commands
Mechanical shock	5000	G	Shock survival limit for internal sensor 5000G for 0.5ms
Weight	735	g	
Connection	SubConn		Fitted with a male 4-pole MCBH4MSS SubConn Micro connector (see page 3)
Depth rating	500	m	Seal rating applies to housing and cable gland. Gland is not designed for flexible cable installation, as this may compromise seal rating




Performance Specifications

Parameter	SUBSEA-05	SUBSEA-15	SUBSEA-30	SUBSEA-45	Unit
Measuring range	±5	±15	±30	±45	°
Zero Bias Error	±0.005	±0.010	±0.015	±0.020	°
Accuracy (@20°C)	±0.010	±0.020	±0.030	±0.040	°
Temperature Errors					
Zero Drift	±0.0015	±0.0015	±0.0015	±0.0015	°/°C
Sensitivity Drift	±0.0030	±0.0030	±0.0030	±0.0030	%/°C
Accuracy 0 to 20°C	±0.045	±0.055	±0.080	±0.100	°
Accuracy -10 to 60°C	±0.070	±0.090	±0.120	±0.150	°
Long Term Stability	±0.007	±0.007	±0.007	±0.007	°
Resolution (@1Hz BW)	0.001	0.001	0.001	0.001	°

Parameter	Notes
Measuring range	Defines the calibrated measurement range. Direction of measurement can be reversed and zero position can be reset anywhere in range. Settings are stored in non volatile memory so are remembered after power down.
Zero Bias Error	This is the maximum angle from the device when it is placed on a perfectly level surface. The zero bias error can be removed from measurement errors either by mechanical adjustment, or as a fixed offset value after installation, or by using the 'setzcur' command to zero the device (see page 8)
Accuracy (@20°C)	This is the maximum error between the measured and displayed value at any point in the measurement range when the device is at room temperature (20°C). This value includes cross axis errors.
Temperature Errors	
Zero Drift	If the device is mounted to a level surface in the zero position, this value is the maximum drift of the output angle per °C change in temperature.
Sensitivity Drift	When the temperature changes there is a change in sensitivity of the sensor's output. The error this causes in the measurement is calculated from the formula: Esd = SD x ΔT x q Where: Esd is the change in output (in degrees) due to sensitivity temperature change SD is the sensitivity drift specification from the above table (0.003%) ΔT is the change in temperature in °C q is the current angle of the inclinometer axis in question in degrees.
Accuracy 0 to 20°C	This is the maximum error between the measured and displayed value at any point in the measurement range when the device is at room temperature (20°C). This value includes cross axis errors.
Accuracy -10 to 60°C	This is the maximum error between the measured and displayed value at any point in the measurement range when the device is at room temperature (20°C). This value includes cross axis errors.
Long Term Stability	Stability depends on environment (temperature, shock, vibration and power supply). This figure is based on being powered continuously in an ideal environment.
Resolution (@1Hz bandwidth)	Resolution is the smallest measurable change in output.




Housing Drawing



Connection Details

The fitted connection is a male 4-pole SubConn Micro series bulkhead connector, part number MCBH4MSS. The pin functions for both RS232 and RS485 variants are shown in the table below:

Pin No.	RS232 Pin Function	RS485 Pin Function
1	+ve Supply	+ve Supply
2	Ground	Ground
3	RS232 Txd	RS485 -
4	RS232 Rxd	RS485 +




View from front end




Axis Direction and Mounting Orientation

Mounted on a Horizontal Surface



Mounted on a Vertical Surface



Note: only the X axis can be used when mounted vertically & the accuracy can't be guaranteed because calibration is performed horizontally.



Part Numbering



Series Prefix

- 05 - ±5° Full Scale Measurement Range
- 15 - ±15° Full Scale Measurement Range
- 30 - ±30° Full Scale Measurement Range
- 45 - ±45° Full Scale Measurement Range

- RS232 - RS232 Interface with LD standard communication protocol
- RS485 - RS485 Interface with LD standard communication protocol
- RS485M - RS485 Interface with ModBus communication protocol

Customer Specific Options (Optional)

Example:

SUBSEA-2-15-RS485M

SUBSEA-2 Series dual axis inclinometer
 ±15° Full Scale Measurement Range
 RS485 Interface with ModBus communication protocol

Certification

The products are type approved to in accordance with the following directive(s):

EMC Directive 2004/108/EC



And it has been designed, manufactured and tested to the following specifications:

BS EN61326-1:2006

Electrical equipment for measurement, control and laboratory use – EMC Requirements

BS EN55011:2007, Group 1
Class B

Certification is available on request.



Level Developments Simplified Control Command Set

Data is transmitted and received over RS232 in full duplex mode and for RS485 versions in half duplex mode. The default configuration is with the baud rate set to 38.4kbps, with 8 data bits, 1 stop bit and no parity. All commands are lower case and 7 bytes long. The time between each character of the command must be less than 100ms otherwise the device will discard the command. The settings are all stored in non volatile memory.

Command	Description	Response Length	Response
get---x	Returns the X axis angle as either: - An INT32 value equal to the angle x 1000 - A fixed length ASCII string terminated with a carriage return depending on the setting of commands 'setoasc' or 'setoint' Shipping default is INT32.	4 bytes 9 bytes	0x XX XX XX XX +025.430<CR>
get---y	Returns the Y axis angle as either: - An INT32 value equal to the angle x 1000 - A fixed length ASCII string terminated with a carriage return depending on the setting of commands 'setoasc' or 'setoint' Shipping default is INT32.	4 bytes 9 bytes	0x YY YY YY YY +025.430<CR>
get-x&y	Returns the X and Y axis angle (X is transmitted first) as either: - A pair of INT32 value equal to the angle x 1000 - A fixed length comma separated ASCII string terminated with <CR> depending on the setting of commands 'setoasc' or 'setoint' Shipping default is INT32.	8 bytes 18 bytes	0x XX XX XX XX YY YY YY YY ±xxx.xxx,±yyy.yyy<CR>
gettemp	Returns the temperature of the sensor as either: - An INT16 value equal to the temperature x 100 - A fixed length ASCII string terminated with a carriage return depending on the setting of commands 'setoasc' or 'setoint' Shipping default is INT32.	2 bytes 6 bytes	0x XX XX ±tt.t<CR>
str9999	Set continuous output transmission rate in milliseconds (25-9999ms) - str0100 - 100ms (0.1s) between transmissions	2 bytes	OK
setcasc	Sets the output to transmit the X and Y angle continuously in ASCII format at the rate defined by strXXXX.	18 bytes	±xxx.xxx,±yyy.yyy<CR>
stpcasc	Stops the continuous transmission of ASCII data	2 bytes	OK
get-flt	Returns the value of the current filter time constant in ms as an INT16	2 bytes	0x XX XX
setdir1 setdir2 setdir3 setdir4	Sets the X axis measurement direction to negative clockwise Sets the X axis measurement direction to positive clockwise Sets the Y axis measurement direction to negative clockwise Sets the Y axis measurement direction to positive clockwise	2 bytes	OK
setzcur	Tare function to set the current position to zero	2 bytes	OK
setzfac	Cancels tare function and resets zero to factory setting	2 bytes	OK
setoasc	Sets the output to ASCII format	2 bytes	OK
setoint	Sets the output to Integer format	2 bytes	OK
setflt1 setflt2 setflt3 setflt4 setflt5 setflt6 setflt7 setflt8	Sets the digital filter frequency response to 0.125Hz Sets the digital filter frequency response to 0.25Hz Sets the digital filter frequency response to 0.5Hz Sets the digital filter frequency response to 1Hz Sets the digital filter frequency response to 2Hz Sets the digital filter frequency response to 4Hz Sets the digital filter frequency response to 8Hz Sets the digital filter frequency response to 16Hz	2 bytes	OK
set-br1 set-br2 set-br3 set-br4 set-br5 set-br6 set-br7	Sets the BAUD rate to 2400bps Sets the BAUD rate to 4800bps Sets the BAUD rate to 9600bps Sets the BAUD rate to 19200bps Sets the BAUD rate to 38400bps Sets the BAUD rate to 57600bps Sets the BAUD rate to 115200bps	2 bytes	OK





Software

A free Windows based application for reading angle, logging and device configuration is available from our website. It requires Windows XP SP3, Windows 7 or Windows 8, and works with 32 and 64 bit systems. It also requires the .net framework V3.5 or higher, and will prompt you to download and install this from Microsoft if it is not already installed on your system. A COM port is also required, and can either be a built in COM port, or a USB to Serial COM port.

The basic features are shown below:

- Automatic or manual configuration of COM port parameters
- Compatible with single or dual axis sensors
- Adjustable number of decimal places on displays
- Logging of data at specified intervals into CSV file
- Setting device to absolute or relative measurement mode
- Switching the data transfer protocol between Integer and ASCII
- Changing the frequency response of the sensor
- Changing the Baud rate of the sensor



We can also offer custom software development services, please contact us for further information.

This software is provided 'as-is', without any express or implied warranty. In no event will the authors be held liable for any damages arising from the use of this software.



ModBus Control Command Set

Data is transmitted and received over RS485 in half duplex mode using the ModBus RTU protocol. The following section provides some basic information about the serial communication between the host PC or PLC and the SUBSEA-2. The full ModBus specification can be obtained from <http://www.modbus.org>. ModBus is a command/response protocol over a serial bus.

The default ModBus serial parameters are: 38400 baud, 1 start bit, 8 data bits, no parity and 1 stop bit. The 8 data bits are sent LSB first. The baud rate can be changed to 115200, 57600, 38400, 19200, 9600, 4800 or 2400 by sending the appropriate command.

The byte order for all 16-bit values is Big Endian (most significant byte first).

Read and write access to the SUBSEA-2 is done using ModBus Function Code 3 (read holding registers) and ModBus Function Code 6 (write single register) commands. These two function codes provide the basic functionality needed by most users of the SUBSEA-2. A user defined ModBus function code 110 is provided for less commonly used, off-line functions such as setting serial port parameters and changing the device address.

ModBus device address must be in the range 1 to 247. All devices are shipped with a default address of 100 (decimal). Address 0 is the ModBus broadcast address. With this address all devices will perform the action of the function code. The maximum number of these devices that can be connected on a single network is 128.

All ModBus commands and responses have a 16-bit CRC for error detection. ModBus RTU data is in binary format rather than ASCII, so it cannot be viewed properly on a text terminal.

Below is a list of the register locations for reading and writing:


ModBus Registers

Parameter	Address	ModBus Register Address	Description	Read/Write
X Axis Angle	0x00	40,001	Address 0x00 returns the upper 16 bits of the sensor X axis angle. This combines with address 0x01 to form a 32 bit signed integer value equal to the measured angle x 1000.	Read Only
	0x01	40,002		
Y Axis Angle	0x02	40,003	Address 0x02 returns the upper 16 bits of the sensor Y axis angle. This combines with address 0x03 to form a 32 bit signed integer value equal to the measured angle x 1000.	Read Only
	0x03	40,004		
Sensor Temperature	0x06	40,007	Returns a 16 bit signed integer value equal to the temperature of the sensor in degrees Celsius x 100	Read Only
Sensor Filter Index	0x09	40,010	Returns a 16 bit integer value between 1 and 7 which relates to a table of filter responses from 0.125 to 16Hz	Read / Write
Tare Function	0x14	40,021	When set to '1' the device is zeroed at the current position (relative mode). When set to '0' the device is returned to absolute measurement mode (tare cancelled)	Read / Write



Frequency Response Filter Indexes

The frequency response of the sensor can be changed to any of the response times shown in the table. The filter is a 2nd order Besel low pass filter implemented in a IIR algorithm.



Filter Index	Freq. Response (Hz)	Damping Time (ms)
1	0.125	8000
2	0.25	4000
3	0.5	2000
4	1	1000
5	2	500
6	4	250
7	8	125
8	16	62.5

Reading a Holding Register

The data from the device is stored in holding registers as detailed on page 4. Function code 0x03 is used to read these registers. Below is the command and response message format, including the error response in the even there is an error.

	Byte Data	No Of Bytes	Description
Command	0x64	1	Slave address 100
	0x03	1	Function code for read register
	0x0000	2	Starting register (0x0000 is X axis angle)
	0x0002	2	Number of registers to read
	0xCDFE	2	CRC-16 of all bytes

Response	0x64	1	Slave address 100
	0x03	1	Function code for read register
	0x04	1	Byte count (2 x number of registers)
	0x0000	2	First and second register data : 0x0000A69C = 42652 (decimal)
	0xA69C	2	
	0xB4FC	2	CRC-16 of all bytes

Error Response	0x64	1	Slave address 100
	0x83	1	ModBus error function code
	0x01	1	Exception Code (0x01 invalid function code, 0x02 invalid register address)
	0x90EF	2	CRC-16 of all bytes

**Writing to a Holding Register**

Data can be written to some registers, such as the registers that store the filter indexes for each axis frequency response. Function code 0x06 is used to write these registers as detailed below.

	Byte Data	No Of Bytes	Description
Command	0x64	1	Slave address 100
	0x06	1	Function code for write register
	0x0009	2	Register to write (0x0009 is axis filter)
	0x0003	2	Data to write (16 bit). 0x0003 = 0.5Hz
	0x103C	2	CRC-16 of all bytes

Response (same as command)	0x64	1	Slave address 100
	0x06	1	Function code for write register
	0x0009	2	Register to write (0x0009 is axis filter)
	0x0003	2	Data to write (16 bit). 0x0003 = 0.5Hz
	0x103C	2	CRC-16 of all bytes

Error Response	0x64	1	Slave address 100
	0x83	1	ModBus error function code
	0x01	1	Exception Code (0x01 invalid function code, 0x02 invalid register address, 0x03 parameter out of range)
	0x90EF	2	CRC-16 of all bytes

Changing the BAUD Rate

The BAUD rate of the device can be changed using the special function code 0x6E and special command code 0x8F.

	Byte Data	No Of Bytes	Description
Command	0x64	1	Slave address 100
	0x6E	1	Function code - 0x6E
	0x8F	1	LD command - 0x8F = set baud
	0x03	1	1 = 2400
			2 = 4800
			3 = 9600
			4 = 19200
			5 = 38400
			6 = 57600
7 = 115200			
0x5AF8	2	CRC-16 of all bytes	



Changing the Device Address

The Address of the device can be changed using the special function code 0x6E and special command code 0x91. The device will reply with the original address in the response, and will change internally after the response has been sent.

Table with 4 columns: Command/Response, Byte Data, No Of Bytes, and Description. It details the sequence of bytes for changing the device address, including slave address, function codes, LD command, new address, and CRC-16.

Examples of Reading Angle

Example 1: Read the angle from the sensor X axis with address 100 (0x64):

Command

```
address (0x64 = 100 decimal)
| function code
| | starting reg. to read (0x0000)
| | | number of reg. to read (0x0002)
| | | |
| | | | CRC-16
| | | |
64 03 00 00 00 02 cd fe
```

Response (positive angle)

```
address (0x64 = 100 decimal)
| function code
| | byte count
| | | angle (0x0000a69c = 42652 decimal (42.652 degrees))
| | | | CRC-16
| | | |
64 03 04 00 00 a6 9c b4 fc
```

Response (negative angle)

```
address (0x64 = 100 decimal)
| function code
| | byte count
| | | angle (0xffffda7d7 = -153641 decimal (-153.641 degrees))
| | | | CRC-16
| | | |
64 03 04 ff fd a7 d7 54 bf
```



Example 2: Read the angle from the Y axis with address 100 (0x64):

Command

```

address (0x64 = 100 decimal)
| function code
| | starting reg. to read (0x0002)
| | | number of reg. to read (0x0002)
| | | |
| | | | CRC-16
| | | |
64 03 00 02 00 02 6c 3e

```

Response (positive angle)

```

address (0x64 = 100 decimal)
| function code
| | byte count
| | | angle (0x00005ba3 = 23459 decimal (23.459 degrees))
| | | |
| | | | CRC-16
| | | |
64 03 04 00 00 5b a3 b4 7c

```

Response (negative angle)

```

address (0x64 = 100 decimal)
| function code
| | byte count
| | | angle (0xfffffa54d = -23219 decimal (-23.219 degrees))
| | | |
| | | | CRC-16
| | | |
64 03 04 ff ff a5 4d 74 74

```

Example 3: Change the frequency response to 0.5Hz:

Command

```

address (0x64 = 100 decimal)
| function code
| | register to write to (0x0009)
| | | data to write (0x0003 = 0.5Hz)
| | | |
| | | | CRC-16
| | | |
64 06 00 09 00 03 10 3c

```

Response

```

address (0x64 = 100 decimal)
| function code
| | register written to (0x0009)
| | | data written (0x0003 = 0.5Hz)
| | | |
| | | | CRC-16
| | | |
64 06 00 09 00 03 10 3c

```



Example 4: Setting the tare function (current position to zero):

Command

```

address (0x64 = 100 decimal)
|  function code
| |  register to write to (0x0014)
| | |  data to write (0x0001 = set tare on)
| | | |
| | | |  CRC-16
| | | |
64 06 00 14 00 01 01 fb

```

Response

```

address (0x64 = 100 decimal)
|  function code
| |  register written to (0x0014)
| | |  data written (0x0001 = set tare on)
| | | |
| | | |  CRC-16
| | | |
64 06 00 14 00 01 01 fb

```

Example 5: Change the device address from 100 to 1:

Command

```

address (0x64 = 100 decimal)
|  special function code
| |  LD command for change address
| | |  new address (0x01)
| | | |
| | | |  CRC-16
| | | |
64 6e 91 01 d2 99

```

Response

```

address (0x64 = 100 decimal)
|  special function code
| |  LD command for change address
| | |  Success/Fail (0x00 = success)
| | | |
| | | |  CRC-16
| | | |
64 6e 91 00 13 59

```